



I-LITE

LED FLOODLIGHT LIGHT IMATE INSTRUCTION BOOK

Warning

This publication contains important safety requirements which must be complied with prior to installation of electrical equipment or any routine maintenance thereof. Replacement of LED lights in the projector is not allowed.

Read carefully the safety requirements below, which apply to all LED projector models. Warning: Electrical appliances can only be installed, operated and repaired by professionals. Do not install or operate LED projectors if one or more components are damaged. Failure to comply with this warning may result in a serious accident or death, or damage to panels and other assets.

Danger of electric shock, electric arc, burn or explosion

Warning: Failure to follow these warnings can result in serious or even fatal injuries.

The projector installation must be entirely the responsibility of a qualified person who is familiar with all relevant instructions.

- Never work alone.
- Before operating the device, disconnect the power from the power grid.
- When checking for power outages, appropriate voltage detection equipment should always be used.
- Disconnect all power and voltages prior to visual inspection, testing, or maintenance of the equipment.
- Considering possible hazards, wear personal protective equipment and carefully check the work area to make sure no tools or other items are left behind.
- Proper operation of the equipment depends on proper operation, installation and use.
- Failure to comply with basic installation requirements can result in injury to persons and damage to electrical equipment and other assets.
- Handling such products requires a range of expertise to protect the grid.
- Only people with the necessary skills can configure and adjust the product.
- Before performing any tests, carefully check every aspect of the installation, primarily the license plate information of the device.

Check network voltage compatibility.

Check that the voltage and current required for the operation of the installed equipment are compatible with the electrical system to which it is connected. First check the label information of the product.

Pay attention to the diameter of the external wiring :

POWER	MIX SURFACE EXPOSED WIRE
< 100W	1.5 ² Rubber Wire
> 100W	2.5 ² Rubber Wire
> 400W	3.5 ² Rubber Wire

